




Tower Assembly. TarpMaster Stationary Tower w/ Single
Function RF (No Lights)


Part Number: 101616

101616 Tower, TarpMaster Tower Assem w/ Single Function RF Wired (No Lights)




Bom ID	Part#	Description	qty
1	10310	TarpMaster Motor 12V. 5 Year Warranty :S/N:	1
2	11328	Wire. 2 Stage Tower Coil 110" - Assembled	1
3	36164	Housing. Spool 98" Aluminum Integrated Housing	1
4	11330	Wire. 6 Ga. Dual Conductor - (per ft)	1
5	101630	Instructions. DC Series Installation	1
6	10912	Electric Kit. 12V With 10698 Relay and RF	1
7	101629	Instructions. DC Series Operating Manual	1

10912 Electric Kit, 12V With 10698 Relay and RF




Bom ID	Part#	Description	qty
1	11000	Switch Kit. RF Receiver w/ keyfob & lanyard	1
2	10695	Relay Kit. HD Mechanical Relay w/ 35 Amp Manual Reset Breaker &...	1

10695 Relay, HD(12V) w/ 35 amp Manual Reset Breaker & Terminal



Bom ID	Part#	Description	qty
1	17918	Breaker. 35A Outdoor Manual Reset Circuit Breaker	1
2	101784	Instructions. 10698 12 volt wiring Diagram	1

36164 Housing, Spool 98" Aluminum Integrated Housing



Bom ID	Part#	Description	qty
1	18260	Bolt. 5/16" x 5/8" Button Head Bolt - Zinc Plated	5
2	18412	Washer. 1/2" Flat Zinc	6
3	18245	Bolt. T-Bolt 1/2-13NCx1.75 for GAB	6
4	18631	Nut. 1/2" Nylock Nut	6
5	36300	Bumper. Rubber Bumper for Tarp Spool (each)	2
6	36331	Bracket. Int Housing Aluminum Endcaps - Drivers Side	2
7	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	6