




Pivot Set. 5 Spring Under-Body Mount w/ 96" Pivot Tubes

(B1-46553 / B2-46552)


Part Number: 46550

46550 Pivot Set, 5 Spring Under-Body Mount




Bom ID	Part#	Description	qty
1	46250	Pivot Tube. AL 5UB/SR spring tube only w/set screws (96")	2
2	103293	Pivot. UB Assembly 5 Spr Drivers	1
3	103294	Pivot. UB Assembly 5 Spr Passenger	1

103293 Pivot, UB Assembly 5 Spr Drivers




Bom ID	Part#	Description	qty
1	46360	Pivot Pin. for 5 & 6 Spring Roller Bearing - Drivers Side	1
2	47800	Bearing. Carrier Underbody Flanged	2
3	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	8
4	102349	Plate. Al Front for Ext Bolt Flange Mount UB Box	1
5	47230	Spring. Spiral Torsion Spring 1 1/4"	5
6	102509	Bracket. Ext Body with holes for 6 Spr UB Box	1
7	102259	Plate. Al Back for Ext Bolt Flange Mount UB Box	1

47800 Bearing, Carrier Underbody Flanged



Bom ID	Part#	Description	qty
1	18628	Nut. Nylock nut 3/8" Jamb Nut	2
2	18242	Bolt. 3/8"-16 x 1 1/8" Button Head	2

103294 Pivot, UB Assembly 5 Spr Passenger



Bom ID	Part#	Description	qty
1	46370	Pivot Pin. for 5 & 6-Spring Roller Bearing - Passenger	1
2	47800	Bearing. Carrier Underbody Flanged	2
3	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	8
4	102349	Plate. Al Front for Ext Bolt Flange Mount UB Box	1
5	47230	Spring. Spiral Torsion Spring 1 1/4"	5
6	102509	Bracket. Ext Body with holes for 6 Spr UB Box	1
7	102259	Plate. Al Back for Ext Bolt Flange Mount UB Box	1