






[SD16000HC. 104" High Cap Housing. 16 Spring 160" UB Pivot.](#)

[22' Extreme Bow Set](#)

Part Number: 68016




Bom ID	Part#	Description	qty
1	36051	Spool Kit. Super Duty High Capacity 104" Housing. w/ Electric Kit. W...	1
2	76723	103 1/2" Wide Extreme Duty Top Tube Kit w/ Extreme Duty 90 Degr...	1
3	46262	Pivot Tube. 22' w/ Set Screws	2
4	76831	Bracket. Pivot Arm Tie Down	2
5	103093	Pivot Set. UB 16 Spring Ext Duty w/ Socket tubes	1



36051 Spool Kit, Super Duty EX Tarp Spool w/104"High Capacity Housing


Bom ID	Part#	Description	qty
1	10122	Super Duty Motor 12V. 5 Year Warranty :S/N:	1
2	36172	Housing. 104" High Capacity Tarp Spool	1
3	31040	Axle. 103" Pre-ThreadedTarp Axle w/Stub Shaft	1
4	31050	Bearing. 3/4" Flanged Axle Bearing with bolts	1
5	18710	Bolt. 5/8" x 1 1/2" Bolt Zinc	8
6	18414	Washer. 5/8" Flat Zinc	16
7	18635	Nut. 5/8" Nylock Nut	8
8	100456	Electric Kit. HD w/Outdoor rotary switch and switch/relay/breaker & ...	1

100456 Electric Kit, HD w/Outdoor rotary switch and switch/relay/breaker mount




Bom ID	Part#	Description	qty
1	10695	Relay Kit. HD Mechanical Relay w/ 35 Amp Manual Reset Breaker &...	1
2	100273	Bracket. AI Relay Switch Breaker Mount for Outdoor Electric Kit	1
3	19265	Switch. 3 Position Outdoor Potted Rotary Switch - No Wire	1
4	17918	Breaker. 35A Outdoor Manual Reset Circuit Breaker	1
5	101784	Instructions. 10698 12 volt wiring Diagram	1

10695 Relay, HD(12V) w/ 35 amp Manual Reset Breaker & Terminal




Bom ID	Part#	Description	qty
1	17918	Breaker. 35A Outdoor Manual Reset Circuit Breaker	1
2	101784	Instructions. 10698 12 volt wiring Diagram	1

76723 Bow Set 104" wide Extreme Duty




Bom ID	Part#	Description	qty
1	76805	Casting. Extreme Duty Corner - 90 Degree (each)	2
2	76814	Flange. Extreme Duty Tarp Centering Flange 6"	2
3	76875	Bow Tube. Extreme Duty "WIDE" Bow Top Tube (103")	1

103093 Pivot Set, UB - 16 Spring Ext Duty




Bom ID	Part#	Description	qty
1	101188	Socket Tube (Drilled & Tapped - 160")	2
2	101007	Pivot. UB Assembled 16-Spr Ext Duty Pass w/o tube	1
3	101006	Pivot. UB Assembled 16-Spr Ext Duty Drivers w/o tube	1

101006 Pivot, UB Assembled 16-Spr Ext Duty Drivers w/o tube




Bom ID	Part#	Description	qty
1	101004	Pivot Pin. for 16-Spring Ext Duty Roller Bearing - Driver	1
1.1	47010	Bushing. Pivot 1 1/4 Machinery Bushing for Pivot Pin	1
1.2	47000	Snap Ring. 1 1/4" External for Pivot Pin	1
2	47800	Bearing. Carrier Underbody Flanged	2
3	47230	Spring. Spiral Torsion Spring 1 1/4"	16
4	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	8
5	102349	Plate. Al Front for Ext Bolt Flange Mount UB Box	1
6	102581	Bracket. Ext Body with holes for 16 Spr UB Box	1
7	102259	Plate. Al Back for Ext Bolt Flange Mount UB Box	1

47800 Bearing, Carrier Underbody Flanged



Bom ID	Part#	Description	qty
1	18628	Nut. Nylock nut 3/8" Jamb Nut	2
2	18242	Bolt. 3/8"-16 x 1 1/8" Button Head	2

101007 Pivot, UB Assembly 16 Spr Ext Duty w/o tube Pass Side, Each



Bom ID	Part#	Description	qty
1	101005	Pivot Pin. for 16-Spring Ext Duty Roller Bearing - Pass	1
1.1	47010	Bushing. Pivot 1 1/4 Machinery Bushing for Pivot Pin	1
1.2	47000	Snap Ring. 1 1/4" External for Pivot Pin	1
2	47800	Bearing. Carrier Underbody Flanged	2
3	47230	Spring. Spiral Torsion Spring 1 1/4"	16
4	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	8
5	102349	Plate. Al Front for Ext Bolt Flange Mount UB Box	1
6	102581	Bracket. Ext Body with holes for 16 Spr UB Box	1
7	102259	Plate. Al Back for Ext Bolt Flange Mount UB Box	1